



## **451 2008 up Engine computer removal**

**Tools Required:  
#20 Torx driver**

**This is the rear cargo area, right side. The ECM is found behind the plastic paneling. You will find one screw in the round detent. Remove it and pull the panel away from the side until you have enough room to access the ECM.**



**The silver metal box is the ECM. Remove the 3 #20 Torx screws holding the ECM to the wall of the car. Unplug the 2 connectors by pulling the black plastic slides on each side until the harness connector is free.**

